


# Menu THC Controller 1.01 (20241023)


## -Start Screen



Status Screen :


ACTIVESTATE : LOW (THC ACTIVE State) : HIGH ( PlasmaDisplay ON (HIGH)/OFF (LOW))

## -Adjust Plasma




UP/DOWN-Button → +/- Plasma Voltage

## -Calibration



Default value 53 → Option to select 50, 53, 100, 200, 25

## -Reset to Default



Do Reset to Default when you will start again. !!!


## -THC Active State



You can change THCU/DOWN to Active HIGH or Active LOW

That means if HIGH THCU/DOWN will have 5V, if LOW THCU/DOWN will have GND when Active

## -Manual THC UP/DOWN



To Test your CNCPlasma without PlasmaBurner

Each Push UP/DOWN-Button (100ms) impulse

If you push more than 500ms it loops 100ms(ON),100(ms(OFF) till release

## -PlasmaDisplay ON/OFF



You can Switch OFF LCD Display Update when PlasmaCutter active.

This make sense when you have fast movment speed.

Because LCD Update takes around 200ms

## - About RHC Controller



THC Controller V1.01  
20241023  
S/N: 32  
mroe@moessler.eu


FW Version / FW Date / PCB Serialnumber /

## During PlasmaCut this are the possible LCD Screens



NO LCD UPDATE  
DURING CUT  
DISABLED

If PlasmaDisplay **OFF**



VPLASMA\_IST: 133.0V  
THCU: Inactive  
THCDOWN: Active

If PlasmaDisplay **ON**



\*\*\*\*\*  
\* PilotARC \*  
\* DETECTED \*  
\*\*\*\*\*

PilotArc Detection only active when  
Internal VoltageDivider is used **1:53**

**Prevent this state because high power over resistors. > 50 W. This Screen appears with Voltage over 240V !! A few ms may be ok. PilotArc can have 5000V-10000V. Find a connection point for PlasmaCutter without PilotArc Voltage. If you are not electrician ask for assistance voltage >50V is dangerous**

## LED States only on during PlasmaCut

**LED1** → Shows Status THC/LCDUpdate →

**ON=THCU/DOWN Active, OFF= LCDUpdate Active**


**LED2** → Shows THCU Status → **ON = ACTIVE, OFF = INACTIVE**

**LED3** → Shows THCDOWN Status → **ON = ACTIVE, OFF = INACTIVE**

## Buttons → SELECT, UP, DOWN

Are only useable when no PlasmaArc is detected !!!

With this Screen on LCD or second Indicator all LED OFF



VPLASMA\_IST: 0.0V  
VPLASMA\_SOLL: 127.2V  
THCU: Inactive  
THCDOWN: Inactive  
ACTIVESTATE: LOW:HIGH